Adjustable-flame burner SCSA





GUANGZHOU SINON COMBUSTION EQUIPMENT CO., LTD.

- (**?**) 020-84581309
- © 020-84507159
- www.gzsinon.net

CHARACTERISTICS

- Additional independent air channel, which can adjust of the flame outlet temperature as required. Flame temperature: 50~1500 °C.
- The secondary air with large flow is supplied independently, which ensures the complete combustion of fuel even in the state of low flame outlet temperature and large excess air coefficient
- High outlet velocity is possible even with low energy supply, the convection heat exchange of furnace is strengthened by the secondary air.
- Fuel: natural gas, LPG, town gas and other fuel gases.

APPLICATIONS

SCSA is mostly used in tunnel kilns, shuttle kilns, roller hearth furnace or other applications need low flame outlet temperature, uniform furnace temperature, and high excess air coefficient, or the industrial kilns need to control the furnace temperature.




CONFIGURATION

- The SCSA is composed of 3 modules: a center burner, a secondary air housing and a SiC ceramic burner tube.
- The center burner is the conventional burner SCEC 65, SCEC 100, or SCEC 140, adopting doubleelectrode ignition/detection. Their air and gas inlets have been installed with orifice plates for pressure measurement.
- The center burner is installed on the secondary air housing. The secondary air housing has its own air interface and the measuring orifice plate needs to be installed separately in the secondary air pipeline, the length of the secondary air housing can be customized as needed.

SPECIFICATION

Parameters

Theoretical flame temperature



Natural gas, air not preheating, calorific valve: 34500~35600 kJ·m⁻³.

Type table

| Туре | SCSA 65 S N -100/235 -SH 0 | | | | | |
|---------------|--|--|--|--|--|--|
| Dimension | 65 100 140 | | | | | |
| Flame shape | L: long flame S: short flame | | | | | |
| Fuel | N: natural gas P: LPG T: town gas | | | | | |
| Standard size | 65: 100/235 100: 150/235 140: 200/285 | | | | | |
| Secondary air | idary air SH 0: standard SH 100: lengthened 100 SH 100+50n: lengthened 100+50n | | | | | |
| housing | 311 0. Standard 311 100. lengthened 100 311 100 3011. lengthened 100 3011 | | | | | |


The burner is lengthened based on its standard size as the secondary air housing is lengthened. For example, the SCSA burner lengthened 50 mm is marked as SH 50.



Dimensions

| Туре | Dimension | SiC tube (interior) | SiC tube (exterior) | Rated capacity /kW | Secondary air flow/m³·h ⁻¹ |
|------|-----------|------------------------|---------------------|-----------------------|--|
| SCSA | 65 | 065/033-300 | 100/050-250 | 50 | 380 |
| SCSA | 65 | 065/033-300 | 100/065-250 | 50 | 600 |
| SCSA | 65 | 065/040-300 | 100/065-250 | 60 | 400 |
| SCSA | 100 | 100/050-350 | 140/070-300 | 130 | 500 |
| SCSA | 100 | 100-065-350 | 140/085-300 | 200 | 500 |
| SCSA | 100 | 100/082-350 | 140/120-300 | 230 | 500 |
| SCSA | 140 | 140/085-350 | 200/107-300 | 320 | 650 |
| SCSA | 140 | 140/120-350 | 200/181-300 | 360 | 750 |


SCSA 65:








SCSA 100:








SCSA 140:








Unit: mm



SOLUTIONS



- High/low pulse control or continuous proportional control.
- Secondary air flow rate is supplied independently and adjusted by solenoid butterfly valve SAM+SKA which is controlled by PLC, The SCSA is mostly used in the furnace with low furnace temperature. Therefore, the burner can be gradually turned down when the temperature is relatively high to adjust the flame outlet temperature.

INSTALLATION

To ensure the measuring accuracy, the length of straight pipe Access pressure section in front of the air inlet should be longer than 5*DN without other resistance elements; and the length of straight pipe section in front of and behind the gas double-flange orifice plate should be longer than 5*DN.

| Access | Pressure /mbar | |
|---------------|-------------------|--|
| Primary air | 50 | |
| Gas | 50 | |
| Secondary air | 60 | |

- The pipe access to the burner must be pre-purged. After installation, make sure that no slag or fuses falling into the pipe or the burner during welding.
- Choose SiC tubes according to furnace temperature.

OPERATION

- Maintenance: SiC tubes, spark insert, flame state and others.
- At least once every six months. Increase the times of maintenance, as appropriate.